


パーツリスト

RAM PARTS LIST (figure b)

Part	Description	Q'ty	Part	Description	Q'ty
R01	Bolt M20x25	1	R14	Busting	1
R02	Gauge Connection Nut	1	R15	O-ring 46.5x1.5	1
R03	Rectagle ring	1	R16	Sping	1
R04	Gauge Coup ler	1	R17	Bolt M8x40	1
R05	Cylinder	1	R18	Nut M6	1
R06	Dust Cop	1	R19	Nut	1
R07	Cop ler and Connecton Nut	1	R20	Upper Round Nut	1
R08	Bolt M5x20	1	R21	Under Round Nut	1
R09	Steel Wire ring	1	R22	Ram	1
R10	Ring	1	R23	Steel Wire ring	1
R11	O-ring 40x5.3	1	R24	Rectagle ring	1
R12	See ling Ring	1	R25	Bolt M6x12	1
R13	O-ring	1	R26	Toe	1



SHOP PRESS PARTS LIST (figure a)

Part	Description	QTY	Part	Description	QTY
01	base supports	2	18	nylon ring	1
02	nuts bolt M10x25	4	19	pressure gauge	1
03	nuts M12	14	20	support pins	2
04	spring washer 12	14	21	bed flat	1
05	washer 12	12	22	heel block	2
06	knighthead	4	23	nuts bolt M12x30	2
07	nuts bolt M10x30	2	24	fixed plate	1
08	post	2	25	nuts bolt M6x16	1
09	nuts M10	6	26	washer 6	1
10	spring washer 10	6	27	nuts bolt M8x16	1
11	washer 10	6	28	washer 8	1
12	nuts bolt M12x35	12	29	press pump	1
13	spreader	1	30	upper crossbeam	2
14	nuts bolt M8x16	2	31	connection nut	1
15	under round nut	1	32	hose fitting	1
16	jack fired seat	1	33	gauge connection nut	1
17	press cylinder	1			

